


Hints on Adjusting the CA12CD

Following this guide should help reduce excessive side tone



1. If the console has a sidetone control adjustment, turn it all the way down
2. Set the receive volume on the console & telephone to just under halfway from minimum
3. Turn the Talk Fine-Adjust (-) volume control on the top of the base **3** all the way down
4. Put the Talk Coarse-Adjust volume control on the bottom of the base **4** on number 4
5. Put the Listen Coarse-Adjust volume control on the bottom of the base **5** on number 4

Make a test call on the telephone and radio to ensure listeners can hear you clearly. If necessary, you can further adjust the talk level with the Talk Fine-Adjust (+) volume control on top of the base unit.